

Fusello

Piano legno / Wooden top	Piano marmo / Marble top	Piano vetro / Glass top
 200 78 3/4" 100 39 1/2"  240 / 280 94 1/2" 110 1/4" 105 41 1/4" 75.2 30"    	 200 78 3/4" 100 39 1/2"  240 / 280 94 1/2" 110 1/4" 105 41 1/4" 76 30" 	 200 78 3/4" 100 39 1/2"  240 / 280 94 1/2" 110 1/4" 105 41 1/4" 74 29 1/4" 